

P-TEC VOICE PAGING SPEAKERS

V-5330100 (VOICE COIL)

V-5330200 (70 VOLT)

INTRODUCTION

P-TEC Voice Paging Speakers are suitable for voice paging as well as background music. The V-5330200 is a 70 Volt model with adjustable taps and volume control. The V-5330100 is a voice coil (45 Ohm) 3.4 Volt model with volume control. P-TEC speakers consist of a 3.6 inch cone speaker mounted in a unique surface-mount baffle. The baffle is designed for mounting on acoustic tile, such as those normally found in suspended-ceilings; and can be mounted without cutting large holes in the tile. The mounting pins can be removed for mounting in a hard ceiling. The speaker housing has screw holes for securing speaker without mounting pins. Although the P-TEC speakers are designed especially for standard suspended ceilings, they can be used on many types of ceiling materials.

DIMENSIONS/WEIGHT

- 8.00" Dia x 2.50" H (20.32cm x 6.35cm)
- Voice Coil** 0.75 lbs. (0.34 kg)
- 70 Volt** 1.25 lbs. (0.57 kg)

INSTALLATION

Selecting the Power-Tap Wire (70V)

Note: For the V-5330100 Speakers (Voice Coil), begin at Suspended Ceiling Installation.

1. Remove the Quick-Connect connector from the accessory pack.
2. Select the desired power-tap wire:
 - Yellow = 1/4W
 - Red = 1/2W
 - Green = 1W
 - White = 2W
 - Blue = 4W

Note: Refer to spacing chart (Figure 6) for recommended speaker spacing.




Figure 1. P-TEC Paging Speaker (70V shown)

3. Install the Quick-Connect connector on the wire. Use pliers to close the connector over the wire. The connector can be removed by prying it open with a screwdriver, and can be reused several times (See Figure 2).




Figure 2. Attaching the Reuseable Quick Connect Connector (V-5330200 only)

4. Connect the power-tap wire to the gold (+) terminal (See Figure 3).
5. Arrange the unused power-tap wires neatly inside the speaker housing and tape them to the inside of the housing.




Figure 3. Connecting the Tap Wire (V-5330200 Only)

Suspended Ceiling

Note: Wrap wires around strain relief posts so speaker wires will not pull free.

1. Lift the adjacent ceiling tile and slide it out of the way.
2. Install the speaker by inserting the mounting pins through the ceiling tile, and hold the speaker in place.
3. Place the wire and washers, and speaker mounting clips over mounting pins (So pins slide through clips).




Figure 4. P-TEC Installation

Note: Washers provide isolation from the pins if the back of the tile is covered with metal foil.

4. If necessary, adjust paging volume after installation. The volume control is located on the side of the speaker. Use a small screwdriver to turn the control.
5. Install the volume control cover found in the accessory pack.

Note: When using a PagePac® Amplicenter, music volume should be adjusted at the paging amplifier or music source. Adjust paging before adjusting background music.

Maintain Speaker Phasing

When using multiple speakers in a single run, keep speakers in phase by connecting the speaker wires to the same spike on each speaker (Either wire can connect on either spike, as long as the pattern is followed on each speaker). The gold spike is the plus (+) terminal (See Figure 5).




Figure 5. Maintaining Speaker Phasing

Handling Shielded Speaker Cable V-5330200 Only

If you are using shielded speaker cable, splice the shield wire at the speaker location so a continuous shield is maintained. When connecting a single speaker or the last speaker on the run, clip the shield wire where it emerges from the outer insulation on the speaker cable.

TECHNICAL ASSISTANCE

When calling, have a VOM and a telephone test set available and call from the job site. Call (540) 563-2000 and press 1 for PagePac Technical Support, or visit our websites at <http://www.pagepac.com> and www.valcom.com.

Should repairs be necessary, attach a tag to the unit clearly stating company name, address, phone number, contact person and the nature of the problem. Send the unit to:

Valcom, Inc.
PagePac® Repair Dept.
5614 Hollins Road
Roanoke, VA 24019-5056

P-TEC SPEAKER PROJECTION DISTANCE

SOUND PRESSURE LEVELS AND WATTAGE SETTINGS FOR 70 VOLT SPK

NOISE LEVEL IN dB	SPL-76 .25 WATT	SPL-78 .50 WATT	SPL-80 1.0 WATT	SPL-83 2.0 WATT	SPL-86 4.0 WATT	
55 dB	26					
56 dB	24					
57 dB	22					
58 dB	20	24				
59 dB	16	22				
60 dB	15	20	24			
61 dB	14	16	22			
62 dB	12	15	20			
63 dB	10	14	16	24		
64 dB	8	12	15	22		
65 dB		10	14	20	24	
66 dB		8	12	16	22	
67 dB			10	15	20	15 FT
68 dB			8	14	16	
69 dB				12	15	
70 dB				10	14	10 FT
71 dB				8	12	
72 dB					10	
73 dB					8	8 FT
74 dB						
75 dB						
76 dB						
77 dB						

MINIMUM MOUNTING HEIGHT

P-TEC SPEAKERS ARE INTENDED FOR USE IN STANDARD 8 FOOT DROPPED CEILING TILE. CEILING HEIGHTS OF MORE THAN 8 FEET OR HIGHER, NOISE LEVELS MAY REQUIRE LESS THAN THE STANDARD 25 FOOT SPACING OR HIGHER TAP SETTINGS.

VALCOM LIMITED WARRANTY

Valcom, Inc. warrants its products only to the original purchaser, for its own use, to be free from defects in materials and workmanship under conditions of normal use and service for a period of one year from the date of shipment. This Limited Warranty obligation shall be limited to the replacement, repair or refund of any such defective device within the warranty period, provided that:

1. inspection by Valcom, Inc. indicates the validity of the claim;
2. the defect is not the result of damage, misuse or negligence after the original shipment;
3. the product has not been altered in any way or repaired by others and that factory sealed units are unopened (a service charge plus parts and labor will be applied to units defaced or physically damaged);
4. freight charges for the return of products to Valcom are prepaid;
5. all units 'out of warranty' are subject to a service charge. The service charge will cover minor repairs (major repairs will be subject to additional charges for parts and labor).

This Limited Warranty is in lieu of and excludes all other warranties, expressed or implied and in no event shall Valcom, Inc. be liable for any anticipated profits, consequential damages, loss of time or other losses incurred by the buyer in connection with the purchase, operation, maintenance, installation, removal or use of the product. The maximum liability of Valcom under this warranty is limited to the purchase price of the specific Product covered by the warranty.

Disclaimer. Except for the Limited Warranty provided herein, the product is provided "as-is" without any warranty of any kind whatsoever including, without limitation, any **WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT.**

This warranty specifically excludes damage incurred in shipment. In the event a product is received in damaged condition, the carrier should be notified immediately. Claims for such damage should be filed with the carrier involved in accordance with the F.O.B. point.

Headquarters:

Valcom, Inc.

5614 Hollins Road Roanoke, VA 24019-5056

Phone: (540) 563-2000 FAX: (540) 362-9800